

KENT JMG

JUICER, MIXER & GRINDER

Best in Class Vegetable Juicer, Mixer & Grinder for Homes

USER MANUAL

KENT
Smart Chef
Appliances

HOUSE of PURITY

500 ⚡
WATT

2 JARS

- 1.5L Blending Jar with Lid
- 1L SS Grinding Jar with Lid



IS 4250



CM/L-9600035913

Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to **KENT**.

At the outset, allow us to thank you for your trust in **KENT Smart Chef Appliances**.

At **KENT**, we take pride in our reputation for quality products that have industry-proven performance. We are certain that you will be more than satisfied with the performance of our **KENT JMG (Juicer, Mixer & Grinder)** and that it will serve you and your family's needs without any compromise.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarize yourself with operation and maintenance.

With the robust quality, you can look forward to years of trouble-free service.

To ensure that the warranty of your appliance is effective, you must fill up the enclosed warranty card and mail it to us within 15 days of purchase.

Please contact your nearest **KENT** dealer if you require any further information.

Bon Appetit!

KENT RO Systems Ltd.

TABLE OF CONTENTS

1. Introduction	1
2. Features of KENT JMG (Juicer, Mixer & Grinder)	1
3. Know Your Product	1
4. Items in the Box	2
5. Using KENT JMG (Juicer, Mixer & Grinder)	2
6. How to Operate	2
7. Modes	3
8. Cleaning and Maintenance	3
9. Precautions	4
10. Important Safety Instructions	4
11. Troubleshooting	5
12. Technical Specifications.....	6

INTRODUCTION

We at **KENT** have always believed that a clean and healthy life is the right of every individual. This ethos made us embark on the journey to develop innovative solutions for purifying the water we drink, the vegetables and fruits we eat, the homes we live in, and the air we breathe.

With the use of innovative technology and the support of a competent service network, we have been able to create a brand that has become synonymous with well-being and health. Continuing with this tradition, we now present the **KENT JMG (Juicer, Mixer & Grinder)**, a new-age high-speed Juicer, Mixer & Grinder for your home that works like magic.

The **KENT JMG (Juicer, Mixer & Grinder)** isn't just any other kitchen appliance. The 2 Jars ensure hygiene, while the ABS plastic body of the main device makes it suitable for regular use, even for longer periods.

Above all, it reduces food preparation time to minutes.

FEATURES OF KENT JMG (JUICER, MIXER & GRINDER)

- Robust Durable Jars
- Automatic Shut Off
- Spill-proof lids
- 500W Powerful Motor
- Ideal for blending vegetables and grinding coffee beans & spices

KNOW YOUR PRODUCT



ITEMS IN THE BOX

- | | |
|---------------------------------|------|
| 1. KENT Juicer Mixer Grinder | : 1N |
| 2. 1.5 L Blending Jar with Lid | : 1N |
| 3. 1 L SS Grinding Jar with Lid | : 1N |
| 4. Pusher | : 1N |
| 5. Spout cover | : 1N |
| 6. Spatula | : 1N |
| 7. Warranty Card | : 1N |

USING KENT JMG (JUICER, MIXER & GRINDER)

1. Remove any stickers that might prevent the unit from operating smoothly.
2. Check the unit for damages. Do not use in case of any damage.
3. Before switching on the appliance, make sure that your home voltage corresponds to the unit's operating voltage.
4. Clean all the parts of the **KENT JMG (Juicer, Mixer & Grinder)** before using the appliance for the first time (see 'Cleaning & Maintenance' section).
5. Make sure all parts are completely dry before you start using the appliance.

HOW TO OPERATE THE JUICER

1. Place juicer housing and the pulp container on the unit. Put spout cover in position. Place glass or bowl under spout.
2. Place juicer mesh into the housing and push down slightly so that the mesh fits and locks properly on the lower coupler of the motor housing. Rotate the mesh a little to see that it fits properly.
3. Place top cover onto juicer housing and lock side clamps. Wash and cut ingredients to fit in feeder opening.
4. Plug in, and rotate the knob to the desired speed. Push the ingredients into the feeder with help of the pusher.
5. At the end of the operation, switch off the Juicer, Mixer & Grinder and unplug. It can be used for juicing carrot, beetroot, spinach etc.

HOW TO OPERATE MIXER/GRINDER

1. Place ingredients in the grinding jar and put lid in position. Place jar on unit and turn the grinding jar.
2. Plug in and support lid gently by hand. Switch on the Juicer, Mixer & Grinder and then move to the higher speed.
3. Switch off after grinding and unplug. Unlock and lift the jar from the unit, and take out the contents.

MODES

BLENDING MODE

This jar can be used to perform all types of blending of vegetable juices etc and grinding operations such as preparation of lassi, milk shakes, purees, juices, etc.

1. Fill the jar with the solids to be blended such as tomatoes and fit the jar on to the main unit.
2. Put the lid on to the jar and push till it fits properly.
3. If needed, more water can be added.
4. Now switch on the mixer for under a minute and you will get finely blended juices and purees.

GRINDING MODE

This jar can be used for grinding items like idli or dosa batter, coconut chutney, groundnuts, red chilli, sugar, palak etc.

1. Fill the jar with ingredients, up to 2/3rd of the capacity of the jar and add some water as per the desired quantity (in case of wet grinding).
2. Put the flat lid on top of the jar, clamp it and fit it onto the main unit.
3. Grind at low speed for about 15 seconds and then move to higher speeds. Keep adding water till you achieve desired consistency.

CLEANING & MAINTENANCE

- Switch off and unplug the appliance before cleaning it
- Remove the lid and clean the jar with warm water and soap solution with the help of a cleaning brush. Never use scouring pads to clean
- Wipe the main unit with a moist cloth and a non-abrasive liquid cleaner
- Do not immerse the appliance in water or any other liquid
- Never put any part of the appliance in the dishwasher
- After cleaning it thoroughly, dry it using a soft cloth
- Ensure that the appliance is completely dry before storing it

Note: Never immerse the motor unit of the blender in water, nor rinse it under the tap

PRECAUTIONS

- Do not disassemble, repair or alter the appliance on your own. It may cause appliance failure or breakdown
- The input voltage must not exceed the rating, it might damage the appliance
- Unplug before cleaning / moving the appliance
- Do not use the appliance with a damaged power cord or plug
- Do not use the appliance near any heat source
- If the appliance is not used for a long time, unplug it
- Do not use the appliance when it is in a recumbent or inclined position
- Do not operate the jars without the lid on them
- Chop food before putting them to mix for better crushing
- While making chutneys or any paste – please put hand on top of the lid to avoid spilling of the liquid
- To avoid overheating of the product - use it for 5 mins, rest for 2 mins & continue the process accordingly to get desired results
- In case of overheating, turn the knob off and rest for 20 mins and push the button at the base of the machine and restart

IMPORTANT SAFETY INSTRUCTIONS


When using an electrical appliance, basic precautions should always be followed, including the following:

1. Unplug, when not in use and before servicing.
2. Always increase the speed gradually a) Low speed – 30s, b) Medium speed – 60s, c) High speed – 90s.
3. To reduce the risk of electric shocks, do not use near or on wet surfaces.
4. Use the appliance only as described in the manual.
5. Do not use the appliance if the cord or the plug is damaged or worn out.
Replace the damaged cord or plug immediately.
6. Do not try to service the appliance on your own. Send it to an authorized service center only.
7. Keep the cord away from heated surfaces.
8. Do not unplug the appliance by pulling the cord. Always unplug by pulling out the plug.
9. To avoid electric shocks, do not use the appliance with wet hands.
10. Keep hair, loose clothing, fingers and all parts of the body away from moving parts.
11. Turn all controls off before unplugging.
12. This appliance is suitable for indoor use only.
13. Keep away from children.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
The appliance does not start.	There is connection problem.	Check if the appliance is connected to the mains and if the plug is inserted firmly into the wall socket.
	The jar is not placed properly.	
	The appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorized service centre for assistance.
The appliance suddenly stops working while running.	The appliance has overheated.	Let the appliance cool for 20 - 30 minutes.
	The appliance is overloaded.	Remove some ingredients, add some water and try again.
	The appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.
The appliance make slots of noise.	The jar is not placed properly.	Reposition the jar in the correct position.
	The blender's inner drive is broken.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.
Motor does not work properly.	The appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.

TECHNICAL SPECIFICATIONS

Product	KENT JMG (Juicer, Mixer & Grinder)
Product Code	116127
Product Generic Name	Juicer, Mixer & Grinder
Net Weight	3.20 kg
Input Power Supply	Single Phase 230 V AC, 50 Hz. 
Total Power Consumption	500 W
Blending Jar	1.5 L
SS Grinding Jar	1 L
Switch & Speed	3 Speed Rotary Switch with Incher
Rating	30 Minute (5 min On / 2 min OFF)
Insulation	Class F
Classificaation	Class II, ordinary (IPX0), Pollution Degree-I
No Load RPM	Approx. 18000+/- 10%
Normal Load in the terms of Cl 2.4 of IS: 4250-1980	Batch Operation of 350g Carrot 100 gms Urad Dal well soaked in adequate quantity of water for 24 Hrs



HOUSE of PURITY



Marketed by:

KENT RO SYSTEMS LTD.

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.

E-mail: sales@kent.co.in

Manufactured by:

STANDARD APPLIANCES INDIA,

Plot No. 41, Sector-5, Parwanoo, Dist. Solan (H.P.)-173220

For customer complaints,

contact our Customer Care Officer at:

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.

Call: 92-789-12345

E-mail: service@kent.co.in or visit us at www.kent.co.in