

KENT POP-UP TOASTER-SILVER

FOR PERFECT & CRISPY TOASTS



Instruction Manual



AUTOMATIC
POP-UP



7 HEATING
MODES



REHEAT
FUNCTION



DEFROST
FUNCTION



CANCEL
FUNCTION



HOUSE OF PURITY

Imported & Marketed by:
KENT RO SYSTEMS LTD.

E-6, Sector-59, Noida, U.P.-201 309, India.

For customer complaints, contact our Customer Care Officer at:
E-6, Sector-59, Noida, U.P.-201 309, India. Call: 92-789-12345
E-mail: service@kent.co.in or visit us at www.kent.co.in

Made in People's Republic of China



750 W



REMOVABLE
CRUMB TRAY



Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to **KENT!**

At the outset, allow us to thank you for your trust in KENT Smart Chef Appliances.

At KENT, we take pride in our reputation for quality products and industry proven performance. We are certain that you will be more than satisfied with **KENT Pop-Up Toaster - Silver** and that it will serve you and your family's needs without any compromise.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarize yourself with the operation and the maintenance of the product.

With its robust and high quality build, you can look forward to years of trouble-free service.

To ensure that the warranty of your appliance is effective, it is important that you fill the enclose warranty card and mail it to us within 15 days of purchase.

In case you require any further information, please contact your nearest KENT dealer or branch.

Bon Appétit!

KENT RO Systems Ltd.

TABLE OF CONTENTS

1. Introduction.....	1
2. Features of KENT Pop-Up Toaster - Silver.....	1
3. Know Your Product.....	1
4. Items in the Box	2
5. Using KENT Pop-Up Toaster - Silver.....	2
6. How to operate	2
7. Cleaning and maintenance	2
8. Precautions.....	3
9. Important Safety Instruction	3
10. Technical Specifications	6

INTRODUCTION

We, at KENT, have always believed that a clean and healthy life is every individual's right. This ethos is what made us embark on a journey to develop innovative solutions for purifying the water that we drink, vegetables and fruits that we eat, homes that we live in and the air that we breathe.

With the use of innovative technology and supported by a competent service network, we have been able to create a brand which has become synonymous with well-being and health. Continuing with the tradition, we now present the KENT Pop-Up Toaster - Silver, a new age kitchen aid to make the perfect toasts from the comfort of your home. KENT Pop-Up Toaster - Silver is so easy to use that you'll put it to work every single day.

FEATURES OF KENT POP-UP TOASTER - SILVER

1. 7 Heating Modes: Achieve the desired colour and crispiness for your toasts easily.
2. Defrost: Defrost frozen bread slices easily in one step.
3. Reheat: Toasts aren't warm anymore? That's okay! Reheat them instantly.
4. Cancel function: You can cancel the toasting process at any time.
5. Removable crumb tray: Cleaning your toaster is now simple. Remove the tray, clean it and slide it back in place.
6. With wide slots, you can easily cook up to 2 slices at a time.
7. Easy to use, clean and store.
8. Automatic Pop-up with anti-jam function.

KNOW YOUR PRODUCT



ITEMS IN THE BOX

1. KENT Pop-Up Toaster - Silver : 1 N
2. Removable Crumb Tray : 1 N
3. User Manual : 1 N

USING KENT POP-UP TOASTER - SILVER

1. Remove any stickers that might prevent normal operations .
2. Check the unit for damages. Do not use in case of any damages .
3. Before switching on the appliance, make sure that your home mains voltage corresponds to the unit's operating voltage.
4. Clean the parts of the KENT Pop-Up Toaster - Silver before using.
5. Make sure all parts are completely dry before you start using the appliance.

HOW TO OPERATE

1. Clean the toaster before using.
2. Plug in the appliance and let it preheat for 2-3 minutes.
Choose the desired setting as per choice.
3. Once heated, put the bread slices and press the lever down.
4. The bread will start to toast.
5. Once the bread is toasted, the pop up toaster would automatically eject it.
6. After cooking, unplug and let it cool before cleaning and storing.

CLEANING & MAINTENANCE

1. Switch off and unplug the appliance before cleaning it.
2. Wipe the main unit with a moist cloth and non-abrasive liquid cleaner.
3. Do not immerse the appliance in water or any other liquid.
4. Never put any part of the appliance in the dishwasher.
5. After cleaning it thoroughly, dry it using a soft cloth.
6. Ensure that the appliance is completely dry before storing it. Never immerse the unit in water, or rinse it under the tap. Wipe it with a dry cloth.

PRECAUTIONS

1. Do not disassemble, repair or alter the appliance on your own. It may cause appliance failure or breakdown.
2. The input voltage must not exceed the rating; it might damage the appliance.
3. Unplug before cleaning / moving the appliance.
4. Do not use the appliance with a damaged power cord or plug.
5. If the appliance is not being used for a long time, unplug it.
6. Do not use the machine when it is in a recumbent or inclined position.

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precaution should always be followed, including the following:

1. Unplug, when not in use and before servicing.
2. After using, unplug and let it cool before cleaning and storing.
3. To reduce the risk of electric shock, do not use near or on wet surfaces.
4. Use the appliance only as described in the manual.
5. Do not use the appliance if the cord or plug is damaged or worn out.
Replace the damaged cord or plug immediately.
6. Do not try to service the appliance on your own. Send it to an authorized service center only.
7. Keep cord away from heated surfaces.
8. Do not unplug the appliance by pulling the cord. Always unplug by pulling the plug and not the cord.
9. To avoid electric shocks, do not use the appliance with wet hands.
10. Keep hair, loose clothing, fingers and all parts of the body away from moving parts.
11. Turn all controls off before unplugging.
12. This appliance is suitable for Indoor use only.
13. Keep away from children.

WARRANTY CARD

Product: **KENT Pop-Up Toaster - Silver**

Product Code: 116168

Serial No.:..... Dealer Stamp:.....

Customer Details:

Customer's Name:.....

Customer's Address:

Customer's Phone No.:

Warranty Details:

Invoice Date:..... Invoice No.:



Imported & Marketed by:
KENT RO SYSTEMS LTD.
E-6, Sector-59, Noida, U.P.-201 309, India.

TERMS & CONDITIONS OF WARRANTY

KENT warrants all new products manufactured by it to be free from defects in material and workmanship under normal usage and service from the date of purchase as under:

1. The Warranty period commences from the date of purchase by the first end-user. During this Warranty period of one year, KENT or its Authorised Service Provider (ASP) will replace or repair any part of KENT Pop-Up Toaster - Silver, that in the opinion of KENT or its ASP, would be defective in operation due to faulty material or workmanship (i.e. manufacturing defects) with the exception of consumables.
2. The product's plastic body is not covered under Warranty and hence, it must be handled with care to guard against breakage.
3. The original purchaser of the unit can avail services under Warranty at the point of sale by producing the damaged part(s) along with the original invoice.
4. This Warranty is void if the unit is not operated under normal conditions or according to the instructions given in the manual.
5. Product returned to KENT or its ASP for Warranty examination must be shipped freight prepaid.
6. KENT or its ASP shall not be held liable for claims exceeding the cost of repair of the defects in workmanship.
7. This Warranty Agreement shall not be interpreted to render KENT or its ASP liable for injuries or damages of any kind - direct, consequential or contingent to persons or property.
8. KENT or its ASP shall not be held responsible by representative or buyer for failure to abide by any of the obligations of this Warranty Agreement, if such failures are the result of circumstances of Forces Majeure such as (but not limited to), floods, earthquakes, transportation strikes, labour disputes with outside suppliers or any other conditions beyond the control of KENT or its ASP.
9. KENT or its ASP shall not be held liable for repair or alterations made without prior written approval for product failures resulting from the lack of proper maintenance.
10. This Warranty Agreement excludes all products/ component parts or damage to any part of this KENT Pop-Up Toaster - Silver which in the opinion of KENT or its ASP have been subjected to misuse; misapplication; negligence; alteration; accident or operation contrary to our instructions. Incompatibility with accessories not installed by KENT or its ASP, or that have been repaired with component parts other than those manufactured by or obtained from KENT or its ASP. Damage caused by freezing, flood, fire or Act of God is not covered by this Warranty. In all such cases, regular charges will apply. This limited Warranty does not include service to diagnose a claimed malfunction in this unit.
11. KENT reserves the right to alter or improve design and specifications at any time, without any contingent obligations to prospective buyers or owners of the products previously sold.
12. Any disagreements and obligations based upon the purchase of KENT products and thereby imposed on KENT or its ASP shall be governed by and construed according to the laws of INDIA and subject to the jurisdiction of Delhi Courts only.
13. KENT or its ASP assumes No Warranty liability in connection with this KENT Pop-Up Toaster - Silver other than that specified herein. This Warranty is in lieu of all other warranties, expressed or implied, including warranties of fitness for a particular purpose. KENT or its ASP does not authorise any person or representative to assume for them any other obligations on the sale of this KENT Pop-Up Toaster - Silver.
14. Under no circumstances, the liability of KENT or its ASP shall exceed the value of the product.
15. Under no circumstances are the terms mentioned above negotiable and no employee of KENT or its ASP has the authority to supersede them.

TECHNICAL SPECIFICATION

Product	KENT Pop-Up Toaster - Silver
Product code	116168
Net Weight	1.10 kg
Input Power Supply	Single Phase 220-240 V AC, 50 Hz.
Power Consumption	750 W
Product Dimensions	265 (L) x 152 (W) x 172 (H) mm