

KENT
Ultra Violet
Water Purifiers
HOUSE of PURITY



Innovations for
Better Living

Marketed by:
KENT RO SYSTEMS LTD.
E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.
E-mail: sales@kent.co.in | Website: www.kent.co.in

Manufactured by:
KENT RO SYSTEMS LTD.
1) Khasra No. 93, Village-Bantakhedi, Tehsil-Roorkee,
District-Haridwar, Uttarakhand-247 668, India.
2) A-6, Sector-87, Noida-201 305, U.P., India.
3) A-7, Sector-87, Noida-201 305, U.P., India.

For customer complaints, contact our Customer Care Officer at:
E-6, 7 & 8, Sector -59, Noida, U.P.-201 309, India. Call: 92-789-12345
E-mail: service@kent.co.in or visit us at www.kent.co.in

KENT ULTRA
UV WATER PURIFIER

Instruction handbook for Installation, Operation and Maintenance.



KENT
Ultra Violet
Water Purifiers

HOUSE of PURITY

3 Stage Advanced
UV Water Purifier



Welcome to KENT

Dear Customer,

At the outset, allow us to thank you for your trust in **KENT** water purifiers. We take pride in our reputation for product quality and industry proven performance. We are certain that your decision to own **KENT ULTRA** water purifier will go a long way towards keeping you and your family in good health. We are confident that you will be satisfied with its performance and that it will serve your need for safe and clean drinking water.

This guide will help you get the best out of your water purifier. Please go through this booklet to familiarize yourself with its operation and maintenance.

You can look forward to years of trouble free service. In case you need any further information, contact your nearest KENT dealer or branch.

Best Wishes

KENT RO SYSTEMS LTD.

Table of Contents

1. Introduction	1
2. Your Water Purifier and its Parts	1
3. Important Instructions	2
4. A look at the UV Process	3
5. Stages of Water Treatment	3
6. UV Fail Alarm	3
7. Purification Flow Chart	4
8. Electrical Circuit Diagram	4
9. Installation Instructions	5
10. Starting-up the Purifier	7
11. Technical Specifications	7
12. Maintenance Tips	8
13. Important Safety Instructions Tips	8
14. Warning	8

Introduction

Presenting the **KENT ULTRA** water purifier; Its Ultra Violet (UV) purification technology is highly effective in killing bacteria & viruses and also reduces all kinds of residual impurities ensuring safe drinking water.

a) **KENT ULTRA** water purifier comes with the following modern features:

- Effective against bacteria, viruses and all kinds of residual impurities including chlorine.
- User-friendly and environmentally safe. Its easy-to-handle process is devoid of any dangerous chemicals or risks factors of overdosing.
- Completely disinfects water without changing its taste, odour and pH scale. With constant conductivity, the general chemistry of water is not hampered.
- Easy to install, all that it requires is a water connection and a power supply.

b) How is **KENT ULTRA** better than other UV based purifiers:

- Wall mountable - best suited for Indian homes and offices.
- Polypropylene (PP) food grade plastic body - for corrosion free service
- Carbon Block Filter Technology- for added protection from bacteria.
- Incorporates UV fail alarm which beeps if UV Lamp is not functional.

Your Water Purifier and its Parts



Please check the following items in the packaged box:

1. KENT ULTRA Water Purifier	:	1 N
2. 3-Way Connector	:	1 N
3. S.S. Ball Valve	:	1 N
4. Food Grade Pipe 0.635 Cm (White)	:	2.5 Meters
5. Warranty Card	:	1 N
6. Screws & Plastic Inserts	:	2 N each
7. Sticker Center Drill	:	1 N

Important Instructions




Avoid exposure to direct sunlight and installation in damp areas.




Make sure that the purifier is connected to cold water supply only.




Use Genuine Kent spares for optimum performance



The maximum distance between the raw water source and the purifier should not be more than 3 meters.




Do not confine the purifier in any kind of cabinet.



Do not try to service the product on your own. Instead, call service technician for help.

A look at the UV Process

The UV light has shorter wavelength (higher energy) than the visible light. Since it comes after the violet light in the light spectrum, it is termed as ultraviolet light. Technically, the wavelength of ultra violet is shorter than 400 nanometer, so it is also termed as electromagnetic radiation. UV-C rays (photons) penetrate into micro-organisms and directly get absorbed in the DNA content of the pathogen. Finally, the DNA is modified in such a way that it stops further reproduction of the organism.



Stages of Water Treatment

Following are the stages of water treatment:

Stage 1 : Inline Sediment


Stage 2 : Inline Carbon

Stage 3 : UV Chamber

UV Fail Alarm

KENT ULTRA has an inbuilt alarm that goes on when the UV Lamp stops drawing sufficient current from the power source. With the help of this unique feature, the user knows whether the UV Lamp is working properly or not. In such circumstances, kindly switch off the purifier and call service technician for help.

Purification Flow Chart




S.NO.	SPARE PART CODE	ITEM DESCRIPTION
1	20010	SEDIMENT FILTER
2	20009	ACTIVATED CARBON FILTER
3	20541	UV CHAMBER
4	20028	SOLENOID VALVE
5	20437	TDS CONTROL VALVE ULTRA

NOTE: Modification in the product may be introduced from time to time and consequently the details given in this manual are subject to alteration without any prior notice.

Electrical Circuit Diagram

S.NO.	SPARE PART CODE	ITEM DESCRIPTION
1	20024	SMPS / BALLAST
2	20028	SOLENOID VALVE
3	20541	UV CHAMBER
4	20540	UV LAMP



Installation Instructions

The KENT ULTRA Purifier is a product of advanced technology that ensures safe and clean drinking water. The purifier is easy and convenient to install.

Recommended Site Preparations :


- Single phase 140-250 V AC, 50-60 Hz, connection not more than 3 meters away from the point of installation.
- Raw water supply with ½ inch nipple, not more than 3 meters away from the point of installation.
- Space as per dimensions of the purifier.
- Wall/plane surface for mounting two screws and holding the water purifier.
- The system and installation must comply with applicable state and local laws & regulation.

Special Instructions:


1. KENT ULTRA is a wall mountable purifier. Make sure that it is only mounted on a wall. Avoid installation on wooden and metallic stands.
2. It is preferable to install the purifier near a sink so that raw water supply is easily available.

Installation Procedure:


1. Screw in the two 10x50 self tapping screws (supplied with the package) on a same horizontal level at a distance of 141 mm from each other in the wall.
2. Carefully hang the purifier on the wall with the help of wall mounting slots present on the back side of the purifier as shown in the figure below.




3. Fix the SS ball valve to the ¼ inch port of the 3-way connector as shown in the figure.




4. Connect the 3-way connector to the raw water supply as shown in the figure. The threaded end of the 3-way connector is fitted in line with the raw water supply. The other end can be connected to a tap or can be plugged off if not required.



5. Connect one end of the white pipe to the SS ball valve and other end to the lower hex connector on the left hand side of the purifier, which is labeled as WATER IN with the help of connector nuts.



6. Before connecting the electric supply, it is important that you perform the following functions:
 - (i) Open the SS ball valve (Handle parallel to the ball valve) to start the flow of water into the purifier.




- (ii) Wait for 2-3 minutes to ensure that the two pre-filters are soaked in water.

Starting-up the Purifier

1. Remove the front cover of the water purifier.
2. Switch on the electrical supply and the power switch of the water purifier.
3. Check the flow rate of the purified water. For effectiveness of the UV treatment, the flow rate of the purified water should not be more than 1 LPM. Adjust the flow rate of the purified water by adjusting the needle control valve.
4. Once the desired flow rate is achieved, switch off the power supply and put back the front cover.
5. The purifier is now ready for use.

Technical Specifications

Product	KENT ULTRA
Product Code	111012
Product Generic Name	Water Purifier
Product Colour	White
Body Material	PP Food Grade Plastic
Mounting	Wall Mounting
Dimensions (mm)	395 (L) x 136 (W) x 340 (H)
Purification Production Rate	60 L/hr. (Depending on Inlet Water Pressure)
Inlet Water Pressure/Temp (min.)	0.3 kg. / cm ² / 10°C
Inlet Water Pressure/Temp (max.)	4.0 kg. / cm ² / 40°C
UV Lamp Wattage	11 W
Life of UV Lamp	5000 hrs. of operation
Total Power Consumption	36 W
Input Power Supply	Single Phase 140-250 V AC, 50-60 Hz. 
Net Weight	3.90 kg.
IP Rating	IPX1

Maintenance Tips

To ensure that the purifier operates at its optimum level, a routine maintenance must be performed. The frequency of the maintenance will greatly depend on raw water quality and consumption of purified water.

- Replace sediment and activated carbon filter after every 12 months, depending on the raw water quality and consumption.
- UV Lamp should be replaced once a year.
- If the purifier is not going to be used for a long time (in case you are on a holiday, tour or out of home), make sure that you disconnect the power supply and turn off the raw water supply.

Note : Filters are consumables. Their replacement time is dependent on the quality of raw water and water consumption. They are not covered under the warranty. However, if the filters choke within 6 months, they will be cleaned / repaired / replaced free of cost. Changing the filter and system inspection is available on call.

Important Safety Instructions

- If the supply cord is damaged, it must be replaced by manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Warning

- Do not operate the UV-C emitter when it is removed from the appliance enclosure.
- Read the maintenance instructions before opening the appliance.
- The appliance must be disconnected from the supply before replacing the UV-C emitter.